



Grid Tied Solar Installation Quick Start Setup Guide.



Grid Tied Solar Installation Setup Guide

1

Before turning on your grid-tied system, ensure the bi-directional meter is installed and your utility company confirmed the system is safe to operate.

Bidirectional Meter



Inverter

AC Disconnect

2

Ensure that the main breaker switch to the home is set to the 'ON' position.




ON

OFF

3

Switch the dedicated solar breaker to the 'ON' position. Look for which breaker is labeled.

4.8 kW inverter = 25a switch
7.6 kW inverter = 40a switch
9.6 kW inverter = 50a switch



Grid Tied Solar Installation Setup Guide

4

Call us to guide you how to turn on AC disconnect. The type of disconnect will vary based on which type of disconnect that was installed.



AC Disconnect

5

On the inverter, switch both the 'ON/OFF' switch and the DC disconnect to the 'ON' position. Some inverter brands only have the DC Disconnect and no OFF/ON.



ON/OFF switch
I = ON, O = OFF



DC Disconnect



6

Log in to your inverter's system monitoring app, and start tracking your energy production! You may need to contact our team to set it up and provide you the login credentials.

